


IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.


**INSTALLING PROJECTOR ON TWO CIRCUITS TRACK TEK / HTEK (1790)
FOR USE WITH TEK SERIES (120V) OR HTEK SERIES (277V) TRACK SYSTEM ONLY**

- A- INSERT THE PROJECTOR TRACK ADAPTOR WITH THE POLARITY GROOVE TOWARDS THE POLARITY RIDGE ON THE TRACK AND PUSH INTO THE TRACK UNTIL IT SNAPS INTO PLACE.
- B- TURN THE MECHANICAL FIXING LEVER TO LOCK THE PROJECTOR INTO THE TRACK.
- C- SELECT THE DESIRED CIRCUIT WITH THE CIRCUIT SELECTOR SWITCH.





REMOVING PROJECTOR FROM TRACK TEK / HTEK (1790)

- A- TO REMOVE THE PROJECTOR FROM TRACK, SELECT 0-POSITION (OFF) ON THE CIRCUIT SELECTOR SWITCH.
- B- TURN THE MECHANICAL FIXING LEVER AS SHOWN TO **UNLOCK** THE PROJECTOR FROM THE TRACK.
- C- PULL FIRST FROM THE FIXING LEVER END TO REMOVE THE PROJECTOR FROM THE TRACK.




PAN ANGLE POSITION (1790)

- A- ADJUST THE DESIRED PAN POSITION. (MAXIMUM OF 330° AXIAL ROTATION).
- B- LOCK THE POSITION WITH THE PAN ADJUSTMENT LOCKING SCREW.



TILT ANGLE POSITION (1790)


- A- ADJUST THE DESIRED POSITION AND LOCK WITH THE LOCKING SET SCREW USING A SLOT SCREW DRIVER. (MAXIMUM OF 90° AXIAL ROTATION)



REPLACING OPTIC

- A- UNSCREW THE OPTIC HOLDER TO ACCESS THE REFLECTOR.
B- REPLACE THE REFLECTOR AND RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A+B



ACCESSORIES

- A- UNSCREW THE OPTIC HOLDER
B- PLACE ACCESSORY BETWEEN THE OPTIC HOLDER AND THE ACCESSORY HOLDER
C- RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A+B+C

