



**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY. USE ONLY IN DRY LOCATIONS.

### INSTALLING PENDANT ON ONE CIRCUIT TRACK (120V)

FOR USE WITH **SISTEMALUX 8000-S1 SERIES** TRACK SYSTEM. ALSO COMPATIBLE WITH COOPER LIGHTING'S HALO® L SERIES TRACKS.



- A- PULL THE ADAPTOR HOUSING DOWN TO INSERT IN THE TRACK FOLLOWING INITIAL POSITION SHOWN BELOW.
- B- PUSH THE PENDANT INTO TRACK AND ROTATE THE TRACK ADAPTOR A QUARTER TURN IN THE PROPER DIRECTION IN ORDER TO ALLOW ELECTRICAL BOUNDING. MAKE SURE THE ADAPTOR IS LOCKED IN PLACE, FOLLOWING FINAL POSITION SHOWN BELOW.



## REMOVING PENDANT FROM ONE CIRCUIT TRACK

A- PULL DOWN THE TRACK ADAPTOR HOUSING TO UNLOCK IT FROM THE TRACK SLOT.

B- HOLDING THE TRACK ADAPTOR HOUSING DOWN, ROTATE A QUARTER TURN IN ANY DIRECTION AND PULL DOWN THE PENDANT TO REMOVE IT FROM THE TRACK.



## REPLACING COMPONENTS

A- UNSCREW THE OPTIC HOLDER TO ACCESS THE COMPONENTS.

B- REPLACE THE REFLECTOR OR OPTIC AND RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

**A + B**

	SMALL 1770	MEDIUM 1780	LARGE 1790
REFLECTOR 20	1740	1736	1715
REFLECTOR 40	1741	1737	1716
REFLECTOR 50	1742	1738	1717
REFLECTOR 60	1743	N/A	N/A
SOFT FOCUS LENS (INCLUDED)		1725	1720
ELLIPTIC LENS	1598	1727	1722
FROSTED LENS	1599	1726	1721
BLACK HEX CELL LOUVER	1596-52	1728-52	1723-52
OPTIC HOLDER			

### ACCESSORIES

- A- UNSCREW THE OPTIC HOLDER.
- B- PLACE ACCESSORY BETWEEN THE OPTIC HOLDER AND THE ACCESSORY HOLDER.
- C- RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

**A + B + C**

