




**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.  
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

**INSTALLING PROJECTOR WITH CANOPY (1790C)  
FOR USE WITH 4" JUNCTION BOX (120V or 120-277V)**

- A- RAISE PROJECTOR TO CEILING AND MAKE ALL NECESSARY CONNECTIONS. **\*FOR OPTIONAL DIMMING 0-10V: WIRES MUST BE RUN THROUGH A SEPARATE KNOCK OUT HOLE WHEN CONNECTING DIMMING CONTROLLER.**  
B- SCREW CANOPY PROJECTOR IN JUNCTION BOX USING THE TWO PHILLIPS HEAD SCREWS PROVIDED.

A + B




\*for reference only

## PAN ANGLE POSITION (1790C)

- A- ADJUST THE DESIRED PAN POSITION. (MAXIMUM OF 330° AXIAL ROTATION).  
B- LOCK THE POSITION WITH THE PAN ADJUSTMENT LOCKING SCREW.

A + B




## TILT ANGLE POSITION (1790C)

- A- ADJUST THE DESIRED POSITION AND LOCK WITH THE LOCKING SET SCREW USING A SLOT SCREW DRIVER.  
(MAXIMUM OF 90° AXIAL ROTATION)

A

\*WARNING: NOT UNLOCKING THE LOCKING SET SCREW TO CHANGE THE TILT ANGLE WILL CAUSE INTERNAL DAMAGE TO THE PROJECTOR.




## REPLACING OPTIC

A- UNSCREW THE OPTIC HOLDER TO ACCESS THE REFLECTOR.

B- REPLACE THE REFLECTOR AND RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A + B



1735 - BRIDGELUX REFLECTOR (24°)

1737 - BRIDGELUX REFLECTOR (34°)

1738 - BRIDGELUX REFLECTOR (48°)

1725 - SOFT FOCUS LENS

1727 - ELLIPTIC LENS

1726 - FROSTED LENS

1728-52 - BLACK HEX CELL LOUVER


## ACCESSORIES

A- UNSCREW THE OPTIC HOLDER

B- PLACE ACCESSORY BETWEEN THE OPTIC HOLDER AND THE ACCESSORY HOLDER

C- RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A + B + C



1730-52 - BLACK CROSS BAFFLE

1729-52 - BLACK SNOOT

1731-52 - BLACK VISOR  
WALL WASHER

1739-52 - BLACK BARN DOORS